

Structured WaterBearer Information Sheet

Structured WaterBearer (SWB)

Chamber Parts:

1. Chamber Ring End (2)
2. Plug (1)
3. Lid (1)
4. Black O-Ring (2)
5. Main Chamber and Blue Sleeve Cover (1)
6. Grip Pad (1)



When you receive your unit, we recommend you rub an oil like olive oil on the black washers to keep them soft and pliable. We recommend you do this periodically as well if you let the unit dry out between uses.

If you have any questions regarding use, here is the phone number for the inventor, Ken Liberty: (520) 398-8385 (Arizona)

NOTE: All Structured WaterBearer Chamber components are NSF certified for drinking water systems.

Accessories including food grade plastic tube and lid (AKA shower head sprayer):



- 1) (Grip pad again)
- 2) Plastic tubing for structured breathing (2 for multiple people use)
- 3) Green / white slip fitting for use with breathing tubes (1)
- 4) Nose plugs (earplugs) for sealing narrow end of NAT portable unit when used for multiple structuring or use as 'water holder'
- 5) Swivel adapter for connection to garden hose, also locking SWB into neck of bottle while pouring with large funnel configuration (1)
- 6) Shower adapter to attach to shower pipe (1)
- 7) O ring seal for one of the multiple structuring configurations (1)
- 8) Plastic tube to use as 'plunger' for a structured breathing configuration, and tube lid with holes for shower head sprayer.
- 9) Bottle of Eucalyptus essential oil with info sheet (for enhanced structured breathing)

Contact Ken Liberty with any technical questions: (520) 398-8385

Or Tim and Victoria White with any customer service questions: (520) 325-3400

For more information, visit <http://structuredwaterandair.com/product/structured-water-bearer/>